



Power supplies and digital inputs not shown for clarity.  
 If you wish SE outputs you should add a Ballsie Lite.  
 Right channel address jumper is only used with Volumite or AC1, not with on-board controller.

				Dual Mono Buf II with IVY III			
				Twisted Pear Audio Russ White			
		SIZE	FSCM NO.	DWG NO.		REV	
		SCALE		Sheet 1			